



STONE OVEN MEDIUM

IT

PULIZIA E SMONTAGGIO DEL BRUCIATORE

Il bruciatore a gas deve essere pulito aspirando periodicamente in modo accurato i residui della cottura. Durante la pulizia di valvole e bruciatori, fare attenzione a non danneggiare il bruciatore.

Prima di procedere alla pulizia occorre estrarre il bruciatore dal forno eseguendo la seguente procedura:

1. Estrarre la manopola anteriore (a).
2. Svitare la vite di fissaggio (b).
3. Togliere il carter di protezione (c) svitando le 2 viti.
4. Estrarre la scatola gas (d) fino a scoprire il collegamento dei cavi di accensione piezoelettrica (e).
5. Scollegare i due cavi di accensione piezoelettrica. Se necessario rimuovere il carter di protezione svitando la vite (f), e rimuovere quindi il bruciatore.

Per rimontare il bruciatore basta eseguire la procedura in senso inverso.

EN

GAS BURNER DISASSEMBLY AND CLEANING

The gas burner should be cleaned periodically by carefully sucking up any cooking residues. When cleaning valves and burners, be careful not to damage the burner.

Before cleaning is necessary to remove the burner from the oven by running the following procedure:

1. Remove the knob (a).

Page 2 / 8

LINK

- > Become a Dealer
- > Careers
- > Register your product
- > Reserved area
- > Faq – Frequently asked questions
- > Privacy Policy

CONTACT

- Alfa Refrattari srl
- Via Osteria della Fontana, 63 - 03012 - Anagni (FR) - Italy
- +39 0775-7821
- +39 0775-782218
- info@alfaforni.com

FOLLOW US ON



CERTIFIED

